



CONDITIONING INSTRUCTIONS

Due to humidity changes, paneling may expand or contract since it is a natural product.

It is strongly recommended that all boards are separated and laid flat in the room where it will be installed.

Once separated, allow the boards to acclimate to the humidity and temperature in the room for at least 72 hours.

Boards that are not allowed to acclimate may exhibit undesired expansion and contraction at the joints.

INSTALLATION INSTRUCTIONS

Begin the first row of paneling at the floor or the ceiling (depending on your preference) of the wall that is being treated.

Attach each row of paneling with a finish nail, driven at an angle, just below the tongue so the next row of paneling conceals the nail heads. When installed in this manner very few fasteners (if any) will be exposed.

EXTERIOR APPLICATIONS

Carefully follow **CONDITIONING INSTRUCTIONS** as noted above.

Paneling is particularly susceptible to changes in humidity/climate when used in exterior applications.

Gapping is required at ends and sides to allow for expansion/contraction. Do not butt up to walls, ceilings or trim on ends or sides.

Follow local building codes and guidelines for venting exterior soffits and ceilings.

Apply paint, stain, or sealer to ALL sides of the product prior to installation.

A minimum 2-1/2" nail must be used and it must penetrate solid wood at 24" o.c. maximum.

Figure 1



Figure 2

